

VILLAGE MARQUEE 30FT X10FT
(Donated by Chris and Jean Stringfield)

To whom it may concern.

Our suggestion as to how best to erect the marquee :

- Unpack the poles which should be bundled by numbers (1,2,3)
- lay out the poles that will make the roof in the shape shown on the suppliers Instruction sheet , in the position you want the marquee erected.
- Place the white plastic connectors in position on the ground and then connect all the poles as per the instructions. (N.B. the poles must have the spring at the end of each pole inserted into the slot of the adjoining pole.)
- Once all the poles and connectors are joined up then slide the roof over the structure ensuring the corners are in place.
- With one person at each point where the vertical poles are to be fitted then lift together (the structure is not very heavy) pushing the poles into place. You must have the poles in the right order otherwise you will have nothing to fix the roof to !!)
- fix the circular base feet into each pole.
- Level up the vertical poles as best you can and ensure the triangular strips hanging from the roof are pulled down tightly and then attached to the bottom part of each pole using the holes provided in the poles – which is why you must have the vertical poles in the right order !
- Finish off securing the tent using the large hooks and guy ropes.
- It is essential you now ensure the roof is secured to the horizontal poles using the velcro ties on the roof which are in the middle of each span.

GOOD LUCK !!